



Use an eyedropper to apply 2 to 3 drops of oil per bowl of water. Do not use 2 to 3 drops each day unless you change the water. When changing the water wipe the inside of the fountain with a clean dry soft cloth. Do not use abrasives on your fountain.